


The Bike Shelf™

BY
KNIFE & SAW
~ SF, CA ~

Thank you for purchasing
The (original) Bike Shelf from
Knife & Saw. I hope you and
your bike enjoy it.

CHRIS BRIGHAM / PRINCIPAL, KNIFE & SAW

In the Box



Included:

1. (1) Bike Shelf
2. (1) Mounting Cleat
3. (1) Socket Head Cap Screw
4. (1) Allen Wrench
5. (5) #8 Pan Head Wall Screws
(in case you lose some)

Tools Needed / Nice to Have:

1. Screw Gun / Drill
2. Phillips Head Screwdriver
3. Level
4. Drywall (or other) Anchors

Instructions

Step 1:

Remove the mounting cleat from The Bike Shelf by removing the bolt on the top/back of The Bike Shelf.


Find and mark the wall stud where you want to hang The Bike Shelf. The mounting cleat has 3 sets of holes. There is one set on each end, as well as one set near the center. **The center holes are meant to be used to attach the mount to a wall stud, while the holes on the ends should be secured with drywall anchors (to be purchased separately).**

Step 2:

Using a level if possible, hold the mounting bracket up to wall at the desired height and mark where the holes line up. Next, pre-drill your marked holes.


Step 3:

Secure the mounting cleat to the wall using screws.



Step 4:

Once mounting cleat is securely attached to the wall, slide The Bike Shelf over and onto it so the opposing cleat on inside back of the shelf locks into it.



Step 5:

Once The Bike Shelf is all the way on the mount and against the wall, re-insert the bolt and tighten it with the provided allen wrench.

Step 6:

Hang your bike and enjoy.

Knife and Saw LLC disclaims all liability for damage or injury resulting from the improper installation or use of The Bike Shelf to the fullest extent permitted by law. The Bike Shelf is intended to be secured to wall studs. Weight limit for hanging bike is 40lbs. Do not ever sit on, stand on, or hang from The Bike Shelf.